

# RG-WALL 1600-N



RG-WALL 1600-N



1.


2.

HA

web	192.168.1.2	80	202.1.1.11	8000
smtp	192.168.1.3	25	202.1.1.11	25

- 1
- 2
- 3
- 4
- 5

DNAT



NAT

IP


IP

IP

/

IP

SNAT










Three overlapping '添加' (Add) dialog boxes are shown, each with a title bar and a close button (X).

- Left Dialog:** Name: 202.1.1.10. Host IP list: 202.1.1.10 (with a red 'x'). Sharing:  允许  禁止 ?
- Middle Dialog:** Name: 192.168.1.2. Host IP list: 192.168.1.2 (with a red 'x'). Sharing:  允许  禁止 ?
- Right Dialog:** Name: 192.168.1.3 (with a red '?' icon). Host IP list: 192.168.1.3 (with a red 'x'). Sharing:  允许  禁止 ?. Buttons: 确定, 取消.

# NAT





NAT

# NAT

添加

基本信息 高级信息 安全引擎

克隆模板

\* 名称 fw706205907

描述

源

源地址 any

源区域

源端口

用户

目的

目的地址 192.168.1.2

目的区域

HTTP

DNAT	webserv	8000
DNAT	IP	80
HTTP	80	

Ruijie Networks

首页

访问控制

全部策略

地址转换

源地址

入侵防御



1.

2.

HA


HA

HA


HA

;

,CPU














```
      "      "      eth0
eth0      IP      192.168.1.201
eth2      eth2      IP
10.1.1.2
```

eth1

# HA




## HA




HA



HA





# THANKS

29

100036

Office Tel: 010-51715999

Fax: 010-51413399

A 11

