





目录 Contents

1





2

3




O.





—	AP /	
3Hz	AP uboot	
—	AP	
3Hz	AP Link down	
—	AP CAPWAP	
3Hz	AP	
—	AP CAPWAP	
3Hz	AP CAPWAP	
3Hz 2 2	AP	



目录 Contents

1



2

3

[illegible]

	11axsupport enable
	no 11axsupport enable
	no 11ax
	Radio 11ax 11ax STA
	dot11radio

	long-gi { 0.8 1.6 3.2 }
	no long-gi
	no 11AX 0.8us
	0.8 OFDM 0.8us
	1.6 OFDM 1.6us
	3.2 OFDM 3.2us
	0.8us
	dot11radio

	ofdma enable
	no ofdma enable
	no ofdma
	dot11radio

目录 Contents

1



2

常用功能配置

3

日常维护和问题排查





RG-AP820-L(V3)
POE DC

802.3af

RG-AP820-L(V3)

AP820-L(V3)

