




AP850(AR)




1024-QAM

802.11ax

2.4G / 5G

MU-MIMO


TWT





RG-AP850(AR)


RG-AP850(AR)



**USB
Reset**


**Console
LAN1/2.5G/PoE
LAN2/IoT
48V**

RG-AP850(AR)



USB
Reset
Console
LAN1/2.5G/PoE
LAN2/IoT
48V

RG-AP850(AR)



RG-AP850(AR) AI radio

AP850(AR)


AI Radio

7*24


(

)

RG-AP850(AR)



RG-AP850(AR)



RG-AP850(AR)

—	AP /	
3Hz	AP uboot	
—	AP	
3Hz	AP Link down	
—	AP	
3Hz	AP	
	2S	
	3S	

RG-AP850(AR)

11AX

- 11ax

	11axsupport enable
	no 11axsupport enable
	no 11ax
	dot11radio

- OFDMA

	ofdma enable
	no ofdma enable
	no ofdma
	dot11radio

RG-AP850(AR) 11AX

- mu-mimo

	mu-mimo enable
	no mu-mimo enable
	no mu-mimo
	dot11radio

AP

MU MIMO

802.11AC

802.11AX

STA

RG-AP850(AR)

	band-optimize he-radio enable				
	no:				
	AC AP	AP	AP	AP	AP

	band-optimize he-radio mode [11axonly 11ac_11ax]				
	11axonly 11ac_11ax	11ax 11ac	11ax	Radio	Radio
	11axonly				
	AC AP	AP	AP	AP	AP

RG-AP850(AR)

-


•

	band-select he-radio access-denial
	[0 10]
	2

•

	band-select he-radio probe-count
	[0 10]
	11axonly

RG-AP850(AR)





THANKS